

**Ruko**<sup>®</sup>

**3+**  
for age



# Quick Start Guide

V1.0.2021.08

## Carle

If you have any questions about this product, please contact Ruko  
by sending a message to [Rukofunnytoys@gmail.com](mailto:Rukofunnytoys@gmail.com)

[www.rukotoy.com](http://www.rukotoy.com)

**Please read the instructions before playing and refer to the user manual for details.**

**1** Charging the robot (about 2h)  
Charging Lamp  
5V/2A  
Not Included



**2** Install batteries for the transmitter


Batteries Not Included



**3** Download and install APP



**5** Turn on transmitter switch




**4** Turn on robot switch



**6** Connect Bluetooth (JT\_XXXX)



**7** Remote control the robot



Walk or glide backward

**8** App control the robot

